KINDER™
EXPERIENCE INNOVATION PRODUCTIVITY

How To Measure Your Elevator Bucket





A: With elevator bucket back laid flat, measure overall length (A).



B: With elevator bucket back laid flat, measure the horizontal projection of the elevator bucket (B).

C: With elevator bucket back laid flat, measure back height (C).



D: With the elevator bucket back held vertical, measure height to front lip (D).

T: Using a micrometer, measure the thickness of the steel bucket. Use a micrometer or ruer for plastic buckets.



AS/NZS ISO 9001
AS/NZS 4801
OHSAS 18001
AS/NZS ISO 14001
BUREAU VERITAS Certification

abn 28 006 489 238

www.kinder.com.au

Kinder Australia Pty Ltd

P | +61 3 8587 9111 F | +61 3 8587 9101 E | sales@kinder.com.au

26 Canterbury Rd, Braeside VIC 3195 (PO Box 1026, Braeside VIC 3195)